



Warranty

THIS WARRANTY IS VALID IN AUSTRALIA AND NEW ZEALAND ONLY.

Each Steelcraft unit is thoroughly inspected in our Quality Assurance department prior to delivery. In the unlikely case that you find any material or workmanship that affects the units normal operation, we will repair the unit free of charge within 12 months of purchase. You are required to present your receipt as proof of purchase. For all concerns with your product please contact our Customer Service Team.

CUSTOMER SERVICE

1300 303 330 - Australia

0508 688 822 - New Zealand

Please read all the information carefully before using this product. This warranty does not apply to failure due to improper care, or normal wear and tear caused by product use. We reserve the right to inspect the unit. You may be charged for repairs if the product has been damaged accidentally.

This warranty does not apply to a stroller used for commercial purposes.

This product is designed to comply with Australian and New Zealand standard AS/NZS2195.

Distributed by:

AUSTRALIA

BRITAX CHILDCARE PTY.LTD.
A Britax International company.
(Incorporated in Victoria)
A.B.N. 55 006 773 600
99 Derby Road, Sunshine,
Victoria 3020, Australia
Phone: (03) 9288 7288
Fax: (03) 9311 5798

NEW ZEALAND

BRITAX CHILDCARE NZ. Limited.
A Britax International company.
101 Diana Drive, Glenfield,
Auckland 9, New Zealand.
Phone: (09) 443 0102
Fax: (09) 443 0120

Due to our continuing program of development, Britax reserves the right to alter the specifications, colour or design without any further notice.

The Steelcraft trademark is the property of Britax Childcare Pty. Ltd-Australia.
Visit the Britax website at: <http://www.britax.com.au> or email us at custserv@britax.com.au

Due to the variations in the style and design of our products the illustrations used in this instruction booklet are generic.

©2010 Copyright Britax Childcare Pty. Ltd. Australia

INSTRUCTION MANUAL



Sonnet Portable cot

BEFORE ASSEMBLING THIS COT READ AND UNDERSTAND THE INSTRUCTIONS.

Do not use mattress other than the one supplied by the manufacturer. Incorrect mattress can cause death.

Use only accessories as recommended by the manufacturers.

Ensure the top rails and base are fully locked.

Stop using this cot if any part of the cot is broken, torn or missing.

KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.




RETAIN FOR FUTURE REFERENCE.
READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND USE
OF THIS COT. ALWAYS FOLLOW THE INSTRUCTIONS.
THE CORRECT USE AND MAINTENANCE OF THIS PRODUCT IS
ESSENTIAL.

WARNINGS: TO AVOID INJURY OR DEATH:

- FOLLOW THE MANUFACTURERS INSTRUCTIONS.
- MAKE SURE CHILDREN ARE KEPT AWAY WHILE YOU ARE ASSEMBLING/DISASSEMBLING THE COT.
- DO NOT LEAVE YOUR CHILD UNATTENDED.
- USE ONLY THE MATTRESS SUPPLIED BY THE MANUFACTURER, INCORRECT MATTRESSES CAN CAUSE DEATH.
- Check that the assembly of the cot is correct and safe.
- Check that all folding parts and locking devices are fully engaged before placing child in the cot.
- Do not place more than one child in the cot at the same time.
- Do not use your cot if any part is torn, broken or missing.
- Cots with padded rails should not be used if the covering fabric has been bitten through.
- Do not use or leave the cot near open fires, naked flames, electric bar fires, gas fires, stoves, heaters or barbecues.
- Do not place the cot where your child could reach medication, money, string, elastic, small toys or other small objects.
- Do not place the cot near trailing or hanging cords, leads or flexes such as electrical cords or leads, etc.
- Do not use additional mattress or padding.

CARE AND MAINTENANCE

- Regularly inspect and maintain you product to ensure the freedom of movements of the locking devices and security of components.
- To prolong the life of your cot keep it clean and do not leave it in the direct sunlight for extended periods of time.
- Removable fabric covers and trims may be cleaned using warm water with a household soap or mild detergent. Allow it to dry fully, preferably away from the direct sunlight.
- Non removable fabric covers and trims may be spot cleaned using a damp sponge with soap or a mild detergent. Allow it to dry completely before folding or storing it away.
- **DO NOT DRY CLEAN OR USE BLEACH.**
- Do not machine wash, tumble or spin dry, unless care labelling on the product permits these methods.
- In some climates the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if damp or wet. Always store the product in a well ventilated area.
- Regularly inspect and maintain you product to ensure the freedom of movements of the locking devices and security of components. To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts.

 **WARNING: IF THE SIDES DO NOT LATCH FIRMLY OR THERE ARE HOLES IN THE MESH SIDES, DISCONTINUE USE IMMEDIATELY AND SEEK REPAIR.**

2. TO FOLD THE COT (Cont)



- F Take the carry bag and cover the folded cot. Finish covering the cot and close zipper.



1. TO OPEN THE COT



! IMPORTANT: THESE STEPS WILL ENSURE THAT THE COT IS CORRECTLY OPENED AND READY TO USE.

- A Unzip the carry bag and remove the cot.
- B Stand the cot on its feet and undo the hook and loop straps that hold the mattress around the frame. Remove the mattress and set it aside.
- C Separate the legs of the cot.



! CAUTION: TAKE CARE, AS FINGER PINCHING CAN OCCUR IN THE CORNER WHEN LOCKING THE RAILS IN PLACE.

- D Beginning with the short rails, quickly pull up with both hands until they lock into place.
- E Now do the same with the longer rails.



1. TO OPEN THE COT (Cont)




NOTE: All the top rails should be locked in place. If they are not, release them and repeat steps D & E. The centre of the cot base must be in a raised position to allow the rails to lock easily. Check for the secure engagement of the rails by pushing down on them.

- F Holding one end of the cot clear of the ground, gently press down on the handle in the middle of the base until the base of the cot is flat. Then turn the handle clockwise to lock the base in position and fold the handle down so it lies flat in the cot base.

! WARNING: USE ONLY THE MATTRESS SUPPLIED BY THE MANUFACTURER, INCORRECT MATTRESSES CAN CAUSE DEATH.

- G Place the mattress into the cot with the padded side facing up.
- H Secure the mattress to the cot by passing the loop straps through the lot in the cot base and pressing it onto the hook attachment strips sewn to the underside of the cot base.



NOTE: Always secure the mattress before using the cot.



2. TO FOLD THE COT

! IMPORTANT: THESE STEPS MUST BE FOLLOWED IN THIS ORDER TO EASILY FOLD THE COT.

- A Release the loop straps that secure the mattress to the cot.
- B Rotate the handle in the middle of the base anti-clockwise and then pull base up approximately 50cm.
- C Release each top rail by lifting the rail slightly and squeezing on the buttons located under the centre joint. The buttons are covered by the top rail fabric and are located at the centre of each rail.
- D Ensure that each rail is fully released and then pull up on the cot base handle while gathering the legs and the frame together until it's fully folded.



NOTE: If the top rails do not fold - Do not force them. Re squeeze the buttons to fully release them.

- E Take the mattress and wrap it around the folded cot with the padded side facing inwards.

