BRITAX CHILDCARE PTY. LTD A Britax International company. (Incorporated in Victoria) A.B.N. 55 006 773 600 99 Derby Road, Sunshine, Victoria 3020, Australia Phone: (03) 9288 7288 Fax: (03) 9311 5798

CUSTOMER SERVICE
1300 303 330 - Australia 0508 688 822 - New Zealand

Due to our continuing program of development, Britax reserves the right to alter the specifications, color or design without any further notice.

The Steelcraft trademark is the property of Britax Childcare Pty.Ltd - Australia.

The Britax trademark is the property of Britax Excelsior Limited - UK.

Visit the Britax website at: www.britax.com.au or email us at au-custserv@britax.com


Due to the variations in the style and design of our products the illustrations used in this instruction booklet are generic.

This product is designed to comply with Australian and New Zealand standard AS/NZS2195:2010

©2010 Copyright Britax Childcare Pty. Ltd. Australia



Sonnet Portable cot



BEFORE ASSEMBLING THIS COT READ AND UNDERSTAND THE INSTRUCTIONS.

Do not use mattress other than the one supplied by the manufacturer. Incorrect mattress can cause death.

Use only accessories as recommended by the manufacturers.

Ensure the top rails and base are fully locked.

Stop using this cot if any part of the cot is broken, torn or missing.

KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.





WARNINGS

RETAIN FOR FUTURE REFERENCE.

READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND USE OF THIS COT. ALWAYS FOLLOW THE INSTRUCTIONS.
THE CORRECT USE AND MAINTENANCE OF THIS PRODUCT IS ESSENTIAL.

WARNINGS: TO AVOID INJURY OR DEATH:

- FOLLOW THE MANUFACTURERS INSTRUCTIONS.
- MAKE SURE CHILDREN ARE KEPT AWAY WHILE YOU ARE ASSEMBLING/DISASSEMBLING THE COT.
- ALWAYS APPLY THE BRAKES WHEN USING THE COT.
- DO NOT LEAVE YOUR CHILD UNATTENDED.
- USE ONLY THE MATTRESS SUPPLIED BY THE MANUFACTURER, INCORRECT MATTRESSES CAN CAUSE DEATH.
- DO NOT ADD ANY EXTRA MATTRESSES AS IT MAY CAUSE SUFFOCATION & DEATH.
- Check that the assembly of the cot is correct and safe.
- Check that all folding parts and locking devices are fully engaged before placing child in the cot.
- Do not place more than one child in the cot at the same time.
- Do not use your cot if any part is torn, broken or missing.
- Do not place toys or other objects in the cot which could provide a step or foothold to help the child climb out.
- Cots with padded rails should not be used if the covering fabric has been bitten through.
- Do not use or leave the cot near open fires, naked flames, electric bar fires, gas fires, stoves, heaters or barbecues.

CARE AND MAINTENANCE

- Regularly inspect and maintain you product to ensure the freedom of movements of the locking devices and security of components.
- To prolong the life of your cot keep it clean and do not leave it in the direct sunlight for extended periods of time.
- Removable fabric covers and trims may be cleaned using warm water with a household soap or mild detergent. Allow it to dry fully, preferably away from the direct sunlight.
- Non removable fabric covers and trims may be spot cleaned using a damp sponge with soap or a mild detergent. Allow it to dry completely before folding or storing it away.
- DO NOT DRY CLEAN OR USE BLEACH.
- Do not machine wash, tumble or spin dry, unless care labelling on the product permits these methods.
- In some climates the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if damp or wet. Always store the product in a well ventilated area.
- Regularly inspect and maintain you product to ensure the freedom of movements of the locking devices and security of components.
 To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts.

WARNING: IF THE SIDES DO NOT LATCH FIRMLY OR THERE ARE HOLES IN THE MESH SIDES, DISCONTINUE USE IMMEDIATELY AND SEEK REPAIR.

THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE.

2. TO FOLD THE COT (Cont)

- D Ensure that each rail is fully released and then pull all the way up on the cot base strap, while gathering the legs and the frame together until it's fully folded.
- E Take the mattress and wrap it around the folded cot with the padded side facing inwards.
- F Thread the straps through the plastic loops, pull them tight and secure using the hook and loop attachments.
- G Take the carry bag and cover the folded cot. Finish covering the cot ensuring the mattress handle is through the opening then close the zipper.





WARNINGS CONTINUED

⚠ WARNINGS

- Do not place the cot where your child could reach medication, money, string, elastic, small toys or other small objects.
- Do not place the cot near trailing or hanging cords, leads or flexes such as curtain cords, electrical cords or leads, etc.
- The thickness of the mattress has been specified to ensure that the
 distance from the top of the mattress to the top of the lowest side
 or end will always be at least 500mm. This will reduce the risk of the
 child falling out of the cot.
- Using the wrong size mattress may create hazardous gaps that could result in suffocation or could reduce the side height of the cot, which may result in your child falling out of the cot.
- Do not use parts or accessories other than those tested and approved by Britax.
- Do not use this cot with a child who can climb out, weighs more than 15kg, or is taller than 90cms.
- Always check parts regularly for tightness of screws, nuts and other fasteners tighten if required.

THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE.

WARNING - MATTRESS SIZE

Using the wrong size mattress may create hazardous gaps that could result in suffocation or could reduce the side height of the cot which may result in your child falling out from the cot.

⚠ IMPORTANT

To ensure the cots correct assembly and use, ensure you follow these instructions in the order they are written.

TESTED AND APPROVED ACCESSORIES

Mattress by Steelcraft - Series B-034/AS2010

2. TO FOLD THE COT

IMPORTANT: THESE STEPS MUST BE FOLLOWED IN THIS ORDER TO EASILY FOLD THE COT.

- A Release the loop straps under the base that secure the mattress and remove the mattress from the cot.
- B Pull the handle up in the middle of the base approximately 50cm.
- C Release each top rail by lifting the rail slightly and squeezing on the buttons, located in the centre joint. The buttons are covered by the top rail fabric and are located at the centre of the rail.





IF THE TOP RAILS DO NOT FOLD - DO NOT FORCE THEM - RE SQUEEZE THE BUTTONS TO FULLY RELEASE THEM.

1. TO OPEN THE COT (Cont)

- H Place the mattress into the cot with its padded side facing up.
- Secure the mattress to the cot by passing the loop straps through the slots in the cot base and pressing it onto the hook attachment strips, sewn to the underside of the cot base.

NOTE: Always secure the mattress before using the cot.





PARTS LIST



A 1 x Carry Bag



B 1 x Mattress



D 1x Cot

1. TO OPEN THE COT

IMPORTANT: THESE STEPS WILL ENSURE THAT THE COT IS CORRECTLY OPENED AND READY TO USE.

- A Unzip the carry bag and remove the cot.
- B Stand the cot on its feet and undo the hook & loop straps that hold the mattress around the frame.
- C Remove the mattress and set it aside.
- D Separate the legs of the cot.









1. TO OPEN THE COT

CAUTION: TAKE CARE, AS FINGER PINCHING CAN OCCUR IN THE CORNERS WHEN LOCKING THE RAILS IN PLACE.

- E Starting with the short rails, pull the centre up with both hands quickly until they are locked in place.
- F Now do the same with the longer rails.



NOTE: All top rails should be locked in place. If they are not, release them and try again. The centre of the cot base must be in a raised position to allow the rails to lock easily. Check for the secure engagement of the rails by pushing down on them.

G Holding one end of the cot clear of the ground, gently press down in the middle of the base until the base lays down flat. The base should now be locked into position.

