



KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

www.britax.com.au

Series SG1009

IMPORTANT NOTES

IMPORTANT NOTES:

ALWAYS FOLLOW THE MANUFACTURERS INSTRUCTIONS. READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND USE OF THIS STROLLER.

THE CORRECT USE AND MAINTENANCE OF THIS PRODUCT IS ESSENTIAL.

- USE GREAT CARE WHEN USING THE STROLLER ON STAIRS, ESCALATORS, TRAVELATORS OR OTHER MOVING SURFACES.
- IT IS RECOMMENDED TO REMOVE THE CHILD FROM THE STROLLER BEFORE GOING UP OR DOWN STAIRS OR ESCALATORS.
- DO NOT LIFT THE STROLLER BY THE ARM BAR (If Supplied) BECAUSE IT MAY DISENGAGE.
- DO NOT ALLOW CHILDREN TO STAND ON THE SEAT.
- DO NOT HANG BAGS OR GOODS FROM THE HANDLE AS THIS COULD CAUSE THE STROLLER TO TIP OVER.
- DO NOT LEAVE THE STROLLER AND ITS ACCESSORIES NEAR AN OPEN FIRE OR EXPOSED FLAME.
- DO NOT PLACE MORE THAN 4 KG IN THE BASKET OR 0.50KG IN THE CUP HOLDER.

WARNINGS



ALWAYS APPLY THE BRAKES WHENEVER THE STROLLER IS STATIONARY.

- DO NOT LEAVE CHILDREN UNATTENDED.
- SECURE THE CHILD IN THE HARNESS AT ALL TIMES.
- DO NOT CARRY EXTRA CHILDREN OR BAGS ON THIS STROLLER.
- MAKE SURE CHILDREN ARE CLEAR OF ANY MOVING PARTS IF YOU ADJUST THE STROLLER.
- DO NOT USE ANY ACCESSORIES OTHER THAN THOSE APPROVED FOR USE WITH THIS STROLLER BY BRITAX.
- IT IS UNSAFE TO USE ACCESSORIES NOT APPROVED FOR USE WITH THIS STROLLER.
- THE MAXIMUM WEIGHT OF THE CHILD USING THIS STROLLER IS NOT TO EXCEED 20 KG.

FOR IMPORTANT NOTES AND WARNINGS ON ACCESSORIES - REFER TO THEIR INDIVIDUAL SECTIONS IN THIS BOOK. THE MAXIMUM WEIGHT VARIES FOR EACH ACCESSORY.



This CAUTION Symbol is shown at certain steps in this Instruction Manual to highlight the danger of being injured by moving parts.

MANUAL HANDLING TECHNIQUES

The **SMART** lifting technique

This technique can be used to pick up small light loads from low levels.

Size up the Load

- Assess the load (size, shape and weight).
- Assess whether the load needs to be moved;
- Where is it going to be placed" Check that there are no obstructions";
- Assess whether mechanical or human assistance is required.

Move the Load as close to the body as possible

- A load is heavier to lift or carry if it is not close to the body.
- The whole hand should be used to ensure a firm grip.

Always bend your knees

- Maintain balance.
- Keep feet apart and in a comfortable position.
- Minimise lower back bending.
- Bend knees preferable at as large an angle as possible but not at a right angle use a semi squat in preference to a full squat.

Raise the load with your legs

- Achieve the lift smoothly and without jerkiness.
- Maintain the normal curvature of the spine to allow the force of the load to be distributed evenly from the spine to the pelvis.

Turn your feet in the direction that you want to move the load

- Avoid unnecessary bending, twisting and reaching.
- Change direction by turning your feet and not your back.
- To set the load down, squat down, keep your head up and let your legs do the work.

Remember to 'THINK TALL' chest lifted, shoulders relaxed, chin tucked in and head level.

IMPORTANT NOTES:

PLEASE REFER TO PAGE 4 FOR SMART LIFTING TECHNIQUES.

- RELEASE THE STORAGE LATCH WITH DUE CARE AND OPEN THE FRAME.
- WHEN OPENING THE STROLLER, BE AWARE OF THE DANGER OF BEING INJURED BY MOVING PARTS AND LOCKING DEVICES DURING THE PROCESS. KEEP ALL HANDS AND LIMBS CLEAR OF THESE PARTS.
- THERE IS POTENTIAL FOR FINGERS OR PARTS OF THE BODY TO BE INJURED WHEN THE STROLLER IS BEING UNFOLDED, DUE CARE SHOULD BE EXERCISED.
- KEEP CHILDREN CLEAR OF THE STROLLER WHEN UNFOLDING THE STROLLER.
- OPEN THE STROLLER SLOWLY AND BE CAREFUL WHERE YOU PLACE YOUR HANDS. KEEPING YOUR HANDS ON THE HANDLE IS THE BEST WAY TO UNFOLD THE STROLLER.

OPENING THE STROLLER


A Stand the stroller upright. Hold the stroller handle with one hand and with the other hand release the storage latch.





OPENING THE STROLLER


B Lift the handle upwards until the stroller is fully opened & locked in position. Push down on the the handle to confirm the frame is locked.






ATTACHING THE SWIVEL WHEELS

A Take each swivel wheel and push it down firmly into each of the wheel mouldings until you hear a 'click ' which indicates the wheel has locked in. Check that each wheel is fully engaged and secured by pulling against it.



REMOVING THE SWIVEL WHEELS

A Locate the metal latch underneath the swivel wheel fork and press in to release & remove the swivel wheel.



ATTACHING THE REAR WHEEL ASSEMBLY

IMPORTANT NOTE: BEFORE ATTACHING THE REAR WHEEL ASSEMBLY TO THE STROLLER, FASTEN THE BASKET SNAPS TOGETHER TO SECURE THE BASKET TO THE STROLLER FRAME.



ATTACHING THE REAR WHEEL ASSEMBLY


A Tip the frame over to install the rear wheel assembly.



B Lower the rear wheel assembly onto the rear legs of the stroller frame and then push down until the locking pins on the stroller frame are fastened securely through the holes on the rear wheel assembly. Pull on the rear wheel assembly to ensure it is correctly installed.



ATTACHING THE REAR WHEEL ASSEMBLY




ATTACHING THE CANOPY

IMPORTANT NOTE:

The sun is very strong. **DO NOT LEAVE YOUR CHILD EXPOSED TO THE SUN.** The canopy on this product will not give your child total protection from the harmful rays of the sun.

- A Slide the canopy mouldings onto the canopy mounting brackets on both sides of the stroller frame until they connect together.
- **B** Attach the hook strip on the side of the canopy backflap to the loop strip on the side of the stroller.






ATTACHING THE ARM BAR

CAUTION: WHEN A CHILD IS IN THE STROLLER IT IS RECOMMENDED THAT THE ARM BAR BE ATTACHED TO THE STROLLER AT ALL TIMES.

A Push the arm bar clips onto each side of the stroller frame until they snap into place. You will hear a 'click' which indicates the arm bar has locked on. Pull up on the arm bar to ensure it has locked into place correctly.



ATTACHING THE CUP HOLDER

WARNING: DO NOT PLACE HOT LIQUIDS IN THE CUP HOLDER.

PLEASE NOTE: The maximum weight placed in the cup holder should not exceed 0.50kg

A Line the cup holder mounting pin with the cup holder bracket on the handle and push the cup holder downwards until it locks into the bracket.






USING THE BRAKES

WARNING: ALWAYS APPLY THE BRAKES WHEN THE STROLLER IS STATIONARY.


- **A** To lock the rear wheels, press the red brake lever down. Push the stroller backwards and forwards to confirm brakes are locked.
- **B** To unlock the rear wheels, push the red brake lever up.



USING THE SWIVEL WHEELS

PLEASE NOTE: Always lock the swivel wheels when using the stroller on rough surfaces as this will minimise wheel wobble. The swivel wheels should only be locked when the wheels are in the trailing position (wheels under frame).


- **A** To lock the front wheels into the fixed position, press the swivel lock up until you hear a 'click'.
- **B** To allow the wheels to swivel, push the swivel wheel lock down until you hear a 'click'.



ADJUSTING THE LEG REST

IMPORTANT NOTES:

- THE LEG REST FEATURE IS PROVIDED FOR YOUR CHILD'S COMFORT.
- THE LEG REST IS NOT DESIGNED TO SUPPORT EXTRA WEIGHT.
- DO NOT ALLOW CHILDREN TO STAND OR SIT ON THE LEG REST. IT WILL DISENGAGE IF EXTRA WEIGHT IS APPLIED.
- **A** Raise the leg rest by lifting it until the release latches lock into place.
- **B** To lower the leg rest, pull the release latches forward located on both sides of the leg rest and then push the leg rest down.



ADJUSTING THE BACKREST



- THE UPRIGHT POSITIONS ARE NOT SUITABLE FOR USE WITH CHILDREN LESS THAN 6 MONTHS OLD.
- THE LOWEST RECLINE POSITION SHOULD BE USED TO TRANSPORT BABIES. THE BACKREST CAN BE ADJUSTED TO A MORE UPRIGHT POSITION AS THE CHILD GROWS OLDER AND IS ABLE TO SUPPORT ITS HEAD WITHOUT ASSISTANCE.

PLEASE NOTE: IF THE CHILD IS SITTING IN THE SEAT, SUPPORT THE BACKREST AS IT RECLINES. IF YOU HAVE DIFFICULTY ADJUSTING THE BACKREST YOU MAY NEED TO REMOVE THE CHILD FROM THE SEAT TO ALLOW YOU TO RAISE OR LOWER THE BACKREST WITH EASE.

A To lower the backrest, lock the brakes (Refer to Page 12). Locate the backrest recline lever on the back of the stroller. Pull the recline lever up and lower the backrest to the desired position.





ADJUSTING THE BACKREST

B To raise the backrest, hold the backrest along the bottom edge and lift to select a more upright seating position.





ADJUSTING THE CANOPY

- **A** To adjust the canopy, open by pulling canopy forward, or close by pushing the canopy backward.
- **B** To open the canopy window, pull the canopy window flap away from the canopy. Roll the canopy window flap up and secure with the elastic loop and toggle.






USING THE HARNESS

WARNING: USE THE HARNESS AT ALL TIMES.


- ENSURE YOUR CHILD IS SECURED WITH A CORRECTLY ADJUSTED HARNESS.
- THE ADJUSTED HARNESS SHOULD CLOSELY FIT THE CHILD.
- NEVER LEAVE THE HARNESS BUCKLED WHEN NOT FITTED TO A CHILD IN THE STROLLER, BECAUSE THE HARNESS CAN FORM LOOPS WHICH MAY POSE A STRANGULATION HAZARD.
- WHEN HARNESS IS NOT IN USE, DISCONNECT SHOULDER STRAPS FROM THE WAIST STRAPS AND BUCKLE TO PREVENT STRANGULATION.
- A five point harness is provided to restrain your child.
- Buckle tongues separate for added safety.
- To reconnect buckle tongues and to secure the child in the harness please follow the steps below carefully.



PLEASE NOTE: Each waist buckle tongue has a raised rib on one side and can only be locked into the buckle assembly with the raised rib facing up.


USING THE HARNESS

A Always apply the brakes. Place child in seat. Slip one shoulder strap over each shoulder. Position crotch strap between legs. Push the buckle tongues (A) on waist straps through the tongue guides (B) on shoulder straps.




PLEASE NOTE: Ensure the straps are not twisted as they may become uncomfortable for the child.

B Hold the buckle tongue (A) on the waist strap & tongue guides (B) on shoulder straps together.




USING THE HARNESS

C Press in and hold the centre crotch buckle button and insert the waist buckle tongues into the crotch buckle assembly.



IMPORTANT: Pull on each waist buckle tongue to make sure they are locked into the crotch buckle assembly. If not, repeat above procedure.


 D Tighten or loosen the shoulder straps and crotch strap by sliding the 3 bar harness adjuster up or down. The crotch strap should be adjusted to a snug fit.




CAUTION: DO NOT SLIDE 3 BAR SLIDER OVER THE SEWN TAB ON SHOULDER HARNESS.

USING THE HARNESS

E Tighten or loosen the waist straps, hold and lift the 4 bar harness adjuster and pull the harness strap to adjust to the desired fit. The waist strap needs to fit firmly around the child.




F Release the harness by depressing the button in the centre of the buckle while pulling the two waist tongues away from the buckle assembly.



USING THE HARNESS


G The stroller seat has 3 sets of harness slots at different heights to accommodate the child. The shoulder straps must be positioned near the child's shoulders. To change the shoulder harness height, push the shoulder harness tongue out of the current harness slot and through the back of the seat and then pull the shoulder harness buckle tongue through the desired slot.



USING THE TETHER STRAP

WARNINGS: USE THE TETHER STRAP TO STOP THE STROLLER ROLLING AWAY.

- THE STROLLER IS DESIGNED FOR USE ON FLAT OR GENTLY SLOPING SURFACES, AND MAY BE UNSTABLE ON HIGHER SLOPING AND UNEVEN SURFACES AND USERS SHOULD BE AWARE OF THE POSSIBILITY OF THE STROLLER ROLLING AWAY OR TIPPING OVER.
- NEVER LET GO OF THE STROLLER WHEN PARKED ON AN INCLINE OR SLOPING SURFACE. ALWAYS PARK ON A FLAT SURFACE.
- A A wrist tether strap is provided near the handle grip. Slide your hand through the tether strap loop whenever you use the stroller. Only remove your hand from the tether strap loop when the brakes have been applied to the stroller wheels.



USING THE STROLLER

PLEASE REFER TO PAGE 4 FOR LIFTING TECHNIQUES.

- Always ensure you bend your knees where appropriate and take due care when lifting the frame.
- With your hand through the wrist tether strap loop, push the stroller holding the handle.
- The stroller can be steered in the desired direction allowing the front wheels to swivel will make this easier.
- The front wheels may wobble or oscillate when walking fast. Locking the front swivel wheels will stop this.
- The stroller can be taken up kerbs by either pressing down on the handles and raising the front wheels or turning the stroller around and pulling the stroller up the kerb.
- Caution is required when pushing the stroller on a steep slope as the stroller may become unstable. Always hold the handles firmly.
- Do not run with the stroller.
- Whenever you stop, always apply the brakes before you leave the stroller.
- Do not hang bags or goods from the handle. Use the storage basket.

FOLDING THE STROLLER


IMPORTANT NOTES:

PLEASE REFER TO PAGE 4 FOR LIFTING TECHNIQUES.

- REMOVE THE CHILD FROM THE STROLLER BEFORE COMMENCING ANY FOLDING OPERATION.
- FOLD THE STROLLER SLOWLY AND BE CAREFUL WHERE YOU PLACE YOUR HANDS.
- WHEN FOLDING THE STROLLER, BE AWARE OF THE DANGER OF BEING INJURED BY MOVING PARTS AND LOCKING DEVICES DURING THE PROCESS. KEEP ALL HANDS AND LIMBS CLEAR OF THESE PARTS.
- THERE IS POTENTIAL FOR FINGERS OR PARTS OF THE BODY TO BE INJURED WHEN THE STROLLER IS BEING FOLDED, DUE CARE SHOULD BE EXERCISED.
- KEEP CHILDREN CLEAR OF THE STROLLER WHEN FOLDING THE STROLLER.
- **A** Remove the child from the stroller before commencing any folding operation.
- B Lock the brakes. (Refer to Page 12)
- C Release the swivel wheels. (Refer to Page 13)
- **D** Unfasten the hook strip on the side of the canopy backflap from the loop strip on the side of the stroller.
- E Raise the backrest to the fully upright position. (Refer to Pages 16)

FOLDING THE STROLLER

- **F** Locate the backrest recline lever (1) on the back of the stroller. Pull the recline lever up and push the backrest forwards.
- **G** Hold the Pull strap (**3 "Pull to fold**) located under the backrest recline lever.



FOLDING THE STROLLER

H Locate the folding lever, (2 "Lift to fold") on the side of the stroller and lift the Pull strap (3 "Pull to fold) and the folding Lever (2 "Lift to fold") upwards at the same time.



FOLDING THE STROLLER

- I The stroller will start to fold. Continue to lift the pull strap (**3 "Pull to fold**) until the stroller has fully folded.
- J The frame lock will automatically engage when the stroller is fully folded. If the frame lock has not engaged, push both sides of the stroller frame together until the frame lock automatically secures the stroller in the locked position.



LIFTING AND CARRYING THE STROLLER

IMPORTANT NOTES:

PLEASE REFER TO PAGE 4 FOR LIFTING TECHNIQUES.

• TO AVOID INJURY: BEND YOUR KNEES WHEN OPENING, LIFTING, CARRYING, FOLDING, UNFOLDING OR ADJUSTING THE STROLLER OR ANY ACCESSORIES.

Please Note: Only use the carry handle to lift and carry the stroller.

A Ensure the storage latch is locked onto the frame before lifting the stroller. To lift the stroller, grasp the carry handle, so the stroller is balanced.



CARE AND MAINTENANCE

- To prolong the life of your stroller keep it clean and do not leave it in the direct sunlight for extended periods of time.
- Removable fabric covers and trims may be cleaned using warm water with household soap or mild detergent. Allow it to dry fully, preferably away from the direct sunlight.
- Non removable fabric covers and trims may be spot cleaned using a damp sponge with soap or a mild detergent. Allow it to dry completely before folding or storing it away.
- In some climates the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if it is damp or wet. Always store the product in a well ventilated area.
- When using your stroller at the beach completely clean your stroller afterwards to remove the sand and salt from the mechanisms and wheel assembly. Sand and Salt will cause premature wear and corrosion.
- If there are compression marks on the tyres Use a domestic hair dryer to gently warm (DO NOT OVERHEAT) the tyre and the compression marks should slowly disappear.
- Always check parts regularly for tightness of screws, nuts and other fasteners tighten if required. To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories approved by Nursery Elegance.

THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE.



BRITAX CHILDCARE PTY. LTD A Britax International company. (Incorporated in Victoria) A.B.N. 55 006 773 600 99 Derby Road, Sunshine, Victoria 3020, Australia Phone: (03) 9288 7288 Fax: (03) 9311 5798

CUSTOMER SERVICE 1300 303 330 - Australia 0508 688 822 - New Zealand

Due to our continuing program of development, Britax reserves the right to alter the specifications, color or design without any further notice.

The Steelcraft trademark is the property of Britax Childcare Pty.Ltd - Australia.

The Britax trademark is the property of Britax Childcare Holdings Limited - UK.

Visit the Britax website at: www.britax.com.au or email us at au-custserv@britax.com

Due to the variations in the style and design of our products the illustrations used in this instruction booklet are generic.

This product is designed to comply with Australian and New Zealand standard AS/NZS2088:2013 "Prams and Strollers - Safety Requirements."

•2015 Copyright Britax Childcare Pty. Ltd. Australia

